

Systems







Low/High Density Timber

- *Kodrin WV 456*







Products

Sikkens Kodrin WV 456

Sikkens Kodrin WV 456 is a water borne sealer for end grains. Kodrin WV 456 is quick drying, translucent, easy to apply and has excellent adhesion to wood and wood primers. Use: In joinery industries as a sealer for end grains to be finished with opaque/translucent waterborne or oil alkyd joinery products **Application:** Stir well. Application temperature must be between 5-30 °C. Apply by using a filling gun or by using a filling knife. **Kodrin WV 456** is a thixotropic paste and can be thinned with water if necessary. Recoatable after 3 hours. Applications of **Kodrin WV456** should be finished before exposure to the elements. See product data

| | |
|---|---------------------------------------|
|  | N/A |
|  | Water if necessary |
|  | 3 hrs at 20°C / 65% relative humidity |
|  | N/A |
|  | Application temperature 5-30°C |
|  | Water |

sheet for full details.

| Key | |
|---|---|
|  | Practical coverage in m ² /ltr per coat, depending on density of timber. |
|  | Thinning % |
|  | Drying time/Recoatable after ... hrs |
|  | Film thickness |
|  | Application temperature °C |
|  | Brush clean up |

See Product Data Sheet for full details on all products.

Directions

- We recommend that you experiment with your chosen system to gain the required technique before the commencement of your project.
- If using a transparent coating system apply the first primer coat of your chosen system to the entire joinery area. If using an opaque system **Kodrin WV 456** can be applied directly to the timber surface. Refer to manufacturers product and application guide for your chosen system and follow all manufactures instructions.
- Ensure timber is cool to the touch before applying **Kodrin WV 456**.
- Using a filling knife, spatula or brush work the **Kodrin WV 456** well into the end grain leaving a clean smooth film over the entire end grain area.
- Using a damp rag clean off the excess from faces of timber.
- Leave to dry.
- Complete coating system chosen. Refer to product and application guide for your chosen system and follow all manufactures instructions.
- Dispose of all materials safely. Do not dispose of any material down stormwater systems. Contact your local council for correct disposal methods.

Directions (continued)

- When undertaking any work always follow good trade, health and safety practices.
- Follow all good coating practices.

Please Note

- Every care is taken to ensure that the information provided in this data sheet is accurate. Jac Jay Limited is unable to guarantee results as it has no control over the conditions under which products are applied, the substrate or the application. The customer has to determine the suitability of the delivered products or information for its intended purpose.